

## Toaster




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	416493	Quarzrohr	406	484001
2	416494	500W/115V		233001
3	416495	1000W/230V		923003




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	345547	Schalter	406	213001
2	110339	Knebel		999045
3	345579	Schalter	412	923011
4	110326	Knebel		999081



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	350028	Timer	406, 412	923012 222001
2	110004	Knebel		999044
3	690010	Zange		433004

## Kontaktgrills




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	416496	700W/230V (oben)	433, 434, 436, 437, 438, 439, G33, G34, G37, G38, G39	921017
1	416497	1000W/230V (unten)		921008
2	690511	Feder		921005




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	359041	Signallampe	433, 434, 436, 437, 438, 439, G33, G34, G37, G38, G39	216012
2	359042	Signallampe		216016
3	390139	Thermostat		921014
4	110285	Knebel		921046 921039

## Friteuse



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	416499	3300W/230V	FRI16	230069
2	416504	3300W/230V	FRI9	230070
3	416505	4950W/400V	FRT9	230068




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	416506	6600W/400V	FRI12, FRI15m	230072
2	416507	8250W/400V	ME15, ME30	230073
3	416508	10950W/400V	ME20, ME40	230074



Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	375507	Sicherheitsthermostat	Universal	236034 236045
2	380238	Schutz	FRI6/9/12/15m	229032
3	380423	Schutz	ME15/20/30/40	229016
4	359041	Signallampe		216012




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	345547	Schalter	ME15, ME20,	213001
2	110339	Knebel	ME30, ME40	447059
3	375618	Thermostat	Universal	236033
				236044
4	110354	Knebel		921002
				447147




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	550061	Fühlerklemme	FRI6/9 (230V)	033286
2	550062	Fühlerklemme	FRI6-15 (400V)	033287
3	n.m.l.	Fühlerklemme	ME_	033278




Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	101131	Minisit		611001
2	101136	Abdeckkappe mit Piezo	MG15, MG20,	611002
3	110068	Knebel	MG30, MG40	447060
4	101265	Unterbrecher		468068




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergleichs-Nr.
1	100192	Zündbrenner		611003
2	102094	Thermoelement	MG15, MG20,	611005
3	100701	Zündkerze	MG30, MG40	611006
4	100026	Zündkabel		611007



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	375200	Sicherheitsthermostat	MG_	236015
2	540699	Auslaufhahn	FRI	720008
3	540646	Auslaufhahn	ME_, MG_	720010



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	970294	Korb	FRI6	706088
2	970295	Korb	FRI9	706089
3	970296	Korb	FRI12, FRI15m	706090



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	970297	Korb 1/2	ME15, ME30,	706097
2	970298	Korb 1/1	MG15, MG30	706092




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	970299	Korb 1/2	ME20, ME40,	706096
2	970300	Korb 1/1	MG20, MG40	706093