

Offene Kochstellen (Elektro)



Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	490016	2000W/230V	4804	8900371
2	490020	2600W/230V		8900370




Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	300025	Schalter (Siebentakt)	4804	8900220
2	110111	Knebel		-
3	359854	Signallampe		8900426
4	359606	Glimmlampe		-

Grillplatten (Elektro)



Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	418235	1600W/230V	1805	8900322
2	418234	1200W/230V	1807	8900323
3	359854	Signallampe	Universal	-
4	359606	Glimmlampe		-




Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	375693	Thermostat	1805, 1807	8900211
2	110114	Knebel, 300°C		-
3	300021	Schalter		8900302
4	110113	Knebel		-

Rostbräter (Elektro)



Abb.	Best.-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415676	400W/230V	1505, 1507, 1509, 1511	8900326
2	211071	Rost		8900580
3	380213	Schütz		8900310



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	380015	Energieregler	1505, 1507,	8900215
2	110117	Knebel		-
3	359855	Signallampe/grün	1509,	8900425
4	359854	Signallampe/gelb	1511	8900426
5	359606	Glimmlampe		

Bratpfannen (Elektro)




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	418234	1200W/230V	2404,	8900323
2	359855	Signallampe	2414	8900425
3	359606	Glimmlampe		




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	380015	Energieregler	2404, 2414	8900215
2	110117	Knebel		-
3	300074	Schalter		8900301
4	110113	Knebel		

Bainmarie



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415675	2000W/230V	2704 (alt)	8900341
2	415375	3000W/230V	2707 (alt)	8900342
3	359854	Signallampe	Universal	8900425
4	359606	Glimmlampe		-

Friteusen (Elektro)




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415365	3300W/230V (außen)	Alte Geräte	-
2	415366	3300W/230V (innen)		-




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415792	6000W/400V	1004, 1006	8900350
2	418237	9900W/400V	1005	8900351



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	375694	Sicherheitsthermostat	1004,	8900253
2	375512	Thermostat	1005,	8900210
3	110115	Knebel	1006	-




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	300021	Schalter		8900302
2	110113	Knebel	1004,	-
3	359854	Signallampe	1005,	8900425
4	359606	Glimmlampe	1006	-

Frittenwannen




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415103	650W/230V		8900319
2	300074	Schalter		8900301
3	110113	Knebel	3204	-
4	359854	Signallampe		8900425
5	359606	Glimmlampe		-



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	970441	Friteusenkorb		8900104
2	550004	Kapillarrohrklemme		8900541
3	550043	Fühlerklemme		8999998

R Salamander (Elektro)

Passend für Roka




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	418236	2600W/230V		3900328
2	380015	Energiregler		8900215
3	110117	Knebel	6397	
4	359855	Signallampe/grün		8900425
5	359606	Glimmlampe		8900425



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	375005	Thermostat		8900203
2	110109	Knebel		-
3	300074	Schalter		8900301
4	110113	Knebel		-

Wärmeschränke




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	418240	1300W/230V		8900327
2	601151	Motor/kpl.		8900360
3	359854	Signallampe		8900426
5	359606	Glimmlampe		-

Wärmebrücken




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Vergl.-Nr.
1	415102	400W/230V		8900380
2	300074	Schalter		8900301
3	110113	Knebel		
4	359855	Signallampe/grün		8900425
5	359606	Glimmlampe		-

