

Offene Kochstellen (Gas)



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	105904	Brennerdeckel, 89mm		10013105619
2	105902	Brennerring		10013111230
3	105898	Brennertulpe		10013117943
4	105899	Düsenträger		10013002540



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	105903	Brennerdeckel, 69mm		10013105629
2	105901	Brennerring		10013111240
3	105900	Brennertulpe		10013117952
4	105899	Düsenträger		10013002540



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	106025	Gashahn		10013161470
2	111884	Knebel		10013144970
3	102056	Thermoelement		10013039501




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	346002	Zündschalter		10013101580
2	346433	Kappe		10013099700
3	101037	Zündgruppe		10013234490, 10001493104
4	102375	Zündkerze		10013116030
5	532508	O-Ring		10013151140




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	210229	Sternrost/seitlich		1009000311, 1360011500
2	210230	Sternrost/mittig		1009001720, 1360011610

Backöfen (Elektro)



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	346432	Schalter		10013101570
2	346433	Kappe		10013099700
3	359718	Backofenlampe/kpl.		10013177630



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	359701	Fassung		-
2	359610	Lampe, 15W		-
3	359709	Linsennippel		-




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	375723	Thermostat		10013023740, 16001142401
2	300114	Vorsatzschalter		10013000860
3	111884	Knebel		10013144970
4	359141	Signallampe		10013000611, 16001518000




Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	415774	Heizkörper/oben		10013150420, 16002032700
2	415775	Heizkörper/unten		10013150430



Abb.	Bestell-Nr.	Beschreibung	Gerätetyp	Ver.-Nr.
1	690037	Scharnier		10013160490
2	700498	Gegenstück		10013160480
3	900511	Türdichtung		10013150180, 1440016280